



## DRAWING FEATURES

- 1 Stud-to-stud centerline of full size panel. Panel width is 44 7/8" unless noted by F.P.
- 2 Dimensions indicating the outside corner to centerline of stud.
- 3 Location of door and dimensions for door opening.
- 4 Symbol G represents location of an optional fixed window.
- 5 Exact dimensional length of floor track sections designated by F.T.
- 6 Dimension for main runner placement from interior of wall.

- 7 Dimension for cross tee placement from interior of wall.
- 8 Location of dust cover support beam (if necessary).
- 9 Dimensions for dust cover placement.
- 10 Dimension for beam braces.
- 11 Description of wall system, panel height and panel color selections.
- 12 Distributor purchase order number given to Porta-Fab.
- 13 Porta-Fab drawing or job number. Refer to this number with all correspondence.

11 → SERIES 300  
 PANEL HEIGHT 8'-0"  
 FINISH: INT: Champagne  
 EXT: Champagne

These documents were developed by PORTA-FAB Corporation. The contents of these documents are the property of PORTA-FAB Corporation. They are not to be copied or otherwise used without the express written permission of PORTA-FAB Corporation.

REV.	SCALE	1/4" = 1'-0"	DATE	 Modular Building Systems P.O. BOX 1084 CHESTERFIELD, MO. 63006-1084	DISTRIBUTOR:	ABC Material Handling	SHEET NO. 1 OF 1
	DRAWN BY	AJ	REVISED		CUSTOMER:	XYZ Manufacturing	
	CHECKED	ED			P.O. 1234	ORDER NO. 18-12345	